
FRENCH FITNESS

OWNER'S MANUAL

FF-VKR20-PT POWER TOWER

Color: Black



CAUTION!

Read all precautions and instructions in this manual before using this equipment.

20220308-V1.0

TABLE OF CONTENTS

BEFORE YOU BEGIN	1
IMPORTANT NOTICE	
HARDWARE IDENTIFIER	3
ASSEMBLY INSTRUCTIONS	4
EXPLODED DIAGRAM	7
PARTS LIST	8

BEFORE YOU BEGIN

Thank you for selecting the FF-VKR20-PT. For your safety and benefit, read this manual carefully before using the machine. As a manufacturer, we are committed to provide you complete customer satisfaction.

IMPORTANT SAFETY NOTICE

PRECAUTIONS

This exercise machine is built for optimum safety. However, certain precautions apply whenever you operate a piece of exercise equipment. Be sure to read the entire manual before you assemble or operate your machine. In particular, note the following safety precautions:

- 1. Keep children and pets away from the machine at all times. DO NOT leave children unattended in the same room with the machine.
- 2. Only one person at a time should use the machine.
- 3. If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, STOP the workout at once. CONSULT A PHYSICIAN IMMEDIATELY.
- 4. Position the machine on a clear, leveled surface. DO NOT use the machine near water or outdoors.
- 5. Keep hands away from all moving parts.
- 6. Always wear appropriate workout clothing when exercising. DO NOT wear robes or other clothing that could become caught in the machine. Running or aerobic shoes are also required when using the machine.
- 7. Use the machine only for its intended use as described in this manual. DO NOT use attachments not recommended by the manufacturer.
- 8. Do not place any sharp object around the machine.
- 9. Disabled person should not use the machine without a qualified person or physician in attendance.
- 10. Before using the machine to exercise, always do stretching exercises to properly warm up.
- 11. Never operate the machine if the machine is not functioning properly.

CARE AND MAINTENANCE


- 1. Inspect and tighten all parts before using the machine.
- 2. The machine can be cleaned using a damp cloth and mild non-abrasive detergent. DO NOT use solvents.
- 3. Maximum user's weight 140 kg.

WARNING: BEFORE BEGINNING ANY EXERCISE PROGRAM, CONSULT YOUR PHYSICIAN. THIS IS ESPECIALLY IMPORTANT FOR INDIVIDUALS OVER THE AGE OF 35 OR PERSONS WITH PRE-EXISTING HEALTH PROBLEMS. READ ALL INSTRUCTIONS BEFORE USING ANY FITNESS EQUIPMENT. WE ASSUME NO RESPONSIBILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE SUSTAINED BY OR THROUGH THE USE OF THIS PRODUCT.

SAVE THESE INSTRUCTIONS.

HARDWARE IDENTIFIER

PLACE WASHER, END OF BOLT, OR SCREW ON CIRCLE TO CHECK FOR CORRECT SIZE.




NOTE: When installing a Aircraft Nut (also called Nylon or Lock Nut), Please use two adjustable wrenches to tighten down the Nut. Hold down the Bolt with one wrench, and use the other wrench to turn the Nut clockwise.











ASSEMBLY INSTRUCTION


Tools required to assembly the machine:
Two Adjustable Wrenches and one Allen Wrench.

NOTE: It is strongly recommended that this machine to be assembled by two or more people to avoid possible injury.

STEP 1 (SEE DIAGRAM 1)

- A.) Connect the two Base Frames (#1) with the Cross Brace (#3) at the bottom. Secure it with two M10 x 3" Bolts (#21), four Ø7/8" Washers (#27), one Bracket (#10), and two M10 Aircraft Nuts (#29) on each side of the Cross Brace (#3).
- B.) Attach a Vertical Frame (#2) to the Base Frame (#1). Secure it with two M10 x $2\frac{1}{2}$ " Bolts (#22), four Ø 7/8" Washers (#27) and two M10 Aircraft Nuts (#29).
- C.) Repeat the above procedure B to install the other side.
- D.) Attach a Diagonal Support (#7) to the Base Frame (#1). Secure it with a M10 x 3"Bolt (#21). two Ø 7/8" Washers (#27) and a M10 Aircraft Nut (#29). Attach the other end to the Vertical Frame (#2). Secure it with a M10 x 3" Bolt (#21), two Ø 7/8" Washers (#27) and a M10 Aircraft Nut (#29). Repeat the same procedure to install the other side.


E.) Attach a Cross Brace (#3) to the Vertical Frames (#2). Secure it with two M10×3" Bolts (#21), four Ø 7/8" Washers (#27), one Bracket (#10), and two M10 Aircraft Nuts (#29) on each side of the Cross Brace.



STEP 2 (SEE DIAGRAM 2)

- A.) Insert an Upper Frame (#5) into the Vertical Frame (#2). Secure it with a M10× 2½ " Bolt (#22), two Ø 7/8" Washers (#27) and a M10 Aircraft Nut (#29).
- B.) Repeat the above procedure A to install the other side.
- C.) Attach Dip Support (#6) to the Upper Frame (#5). Secure it with two M10×3"Bolts (#21), four Ø 7/8" Washers (#27), two M10 Aircraft Nuts (#29) and one Long Bracket (#15).
- D.) Repeat the above procedure C to install the other side.
- E.) Connect both Dip Supports (#6) with a Backrest Support (#4). Secure it with two M10× 3" Bolts (#21), four Ø 7/8" Washers (#27), two M10 Aircraft Nuts (#29) and a Bracket (#10) on each side of the Support.


DIAGRAM 2




STEP 3 (SEE DIAGRAM 3)

- A.) Attach an Arm Pad (#11) to the Dip Support (#6), Secure it with two M8 x 2 ½" Bolts (#25) and Ø 3/4" Washers (#28). Attach a Handle (#8) to the Dip Support. Secure it with a M10 × 1" Bolt (#24) and Ø 7/8" Washer (#27).
- B.) Repeat the above procedure A to install the other side.
- C.) Attach the Backrest Pad (#12) to the Backrest Support (#4). Secure it with two M8 x 5/8" Bolts (#26) and Ø 3/4" Washers (#28).
- D.) Lubricate the inside of the 20" Foam Grip (#14) with water and slide it onto the Chip Up Bar (#9)
- E.) Slide the two short Foam Grips (#13) onto the bar.
- F.) Attach the Chin Up Bar (#9) to the Upper Frames (#5), Secure it with two M10×1 $\frac{3}{4}$ " Allen Bolts (#23) and Ø 7/8" Washers (#27).

DIAGRAM 3



EXPLODED DIAGRAM



Trpt Parts List

Part	NO. DESCRIPTION	Q'ty
		_
1	Base Frame	2 2
2	Vertical Frame	2
3	Cross Brace	2
4	Backrest Support	1
5	Upper Frame	2 1 2 2 2 2 1
6	Dip Support	2
7	Diagonal Support	2
8	Handle	2
9	Chin UP Bar	1
10	Bracket	6
11	Arm Pad	2
12	Backrest Pad	1
13	Foam Grip	2
14	20" Foam Roll	2 1 2 1 2 4
15	Long Bracket	2
16	2" Square End Cap	4
17	Ø 1" R-Shape End Cap	4
18	2" Sleeve	2 2 2
19	Ø 1" Long Grip	2
20	Ø 1 ½ "Grip	
21	M10 x 3" Bolt	20
22	M10 x 2 1/2" Bolt	6
23	M10 x 1 3/4" Allen Bolt	2 2
24	M10 x 1" Bolt	2
25	M8 x 2 1/2" Bolt	4
26	M8 x 5/8" Allen Bolt	2
27	Ø 7/8" Washer	56
28	Ø ¾" Washer	6
29	M10 Aircraft Nut	26
30	#6 Allen Wrench (Tool)	1
31	Ø 1" Short Grip	2