

FRENCH FITNESS

OWNER'S MANUAL

FF-FSR50-MONOLIFT

Color: Black





CAUTION!

Read all precautions and instructions in this manual before using this equipment. 20230216-V1.0

TABLE OF CONTENTS

BEFORE YOU BEGIN	1
IMPORTANT SAFETY NOTICES	2
HARDWARE PACK	3
ASSEMBLY INSTRUCTIONS	4
EXPLODED DIAGRAM	4
PARTS LIST	5

BEFORE YOU BEGIN

Thank you for selecting the FF-FSR50-MONOLIFT. For your safety and benefit, read this manual carefully before using the machine. As a manufacturer, we are committed to provide you complete customer satisfaction.

IMPORTANT SAFETY NOTICE


PRECAUTIONS


This exercise machine is built for optimum safety. However, certain precautions apply whenever you operate a piece of exercise equipment. Be sure to read the entire manual before you assemble or operate your machine. In particular, note the following safety precautions:


- 1. Keep children and pets away from the machine at all times. DO NOT leave children unattended in the same room with the machine.
- 2. Only one person at a time should use the machine.
- 3. If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, STOP the workout at once. CONSULT A PHYSICIAN IMMEDIATELY.
- 4. Position the machine on a clear, leveled surface. DO NOT use the machine near water or outdoors.
- 5. Keep hands away from all moving parts.
- 6. Always wear appropriate workout clothing when exercising. DO NOT wear robes or other clothing that could become caught in the machine. Running or aerobic shoes are also required when using the machine.
- 7. Use the machine only for its intended use as described in this manual. DO NOT use attachments not recommended by the manufacturer.
- 8. Do not place any sharp object around the machine.
- 9. Disabled person should not use the machine without a qualified person or physician in attendance.
- 10. Before using the machine to exercise, always do stretching exercises to properly warm up.
- 11. Never operate the machine if the machine is not functioning properly.
- 12. Max Drop Weight: 90kg

WARNING: BEFORE BEGINNING ANY EXERCISE PROGRAM, CONSULT YOUR PHYSICIAN. THIS IS ESPECIALLY IMPORTANT FOR INDIVIDUALS OVER THE AGE OF 35 OR PERSONS WITH PRE-EXISTING HEALTH PROBLEMS. READ ALL INSTRUCTIONS BEFORE USING ANY FITNESS EQUIPMENT. WE ASSUME NO RESPONSIBILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE SUSTAINED BY OR THROUGH THE USE OF THIS PRODUCT.

SAVE THESE INSTRUCTIONS.







PARTS LIST

KEY NO.	PART DESCRIPTION	SPEC	QTY
1	Left Safe Catch		1
2	Right Safe Catch		1
3	Rubber Bumper	60×55×5	4
4	Rubber Bumper	120×55×5	4
5	Rubber Bumper	70×55×5×φ26	2
6	Rotating Frame		2
7	Sleeving	φ16×φ10.2×40	2
8	Rack Liner		2
9	Rack Liner		4
10	Locking Knob		2
11	Bushing	φ25×φ22×φ16×10	4
12	Hex Bolt	M8×35	8
13	Washer	8	16
14	Washer	10	4
15	Aircraft Nut	M8	8
16	Aircraft Nut	M10	2
17	Hex-lob Screw	M6×10	4
18	Hex Bolt	M10×	2
	Allen wrench	4#	1